

AI69A - AI69A

ATTACCHI SPECIFICI PER - SPECIFIC FITTING KIT FOR  
KIT DE MONTAGE SPECIFIQUE POUR - SPEZIFISCHER MONTAGEKIT F R  
ANLAJE ESPECCEFICO PARA

# SUZUKI SIXTEEN 2008 125/150cc

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE


**1**



**SUPPORTO**  
SUPPORT  
SUPPORT  
HALTERUNG  
SOPORTE

**Q.TY n.2(Dx-Sx)**


**2**



**VITE TBEI M6x30mm**  
NERA  
SCREW  
VIS  
SCHRAUBE  
TORNILLO

**Q.TY n.4**

**3**



**VITE TEF M8x35mm**  
SCREW  
VIS  
SCHRAUBE  
TORNILLO

**Q.TY n.4**

**4**



**DISTANZIALE f18x18mm**  
Foro f8mm, V545  
SPACER  
ENTRETÔISE  
Distanzstueck  
Distanciador

**Q.TY n.4**

**5**



**DISTANZIALE f10x7mm**  
Foro f7mm, V140  
SPACER  
ENTRETÔISE  
Distanzstueck  
Distanciador

**Q.TY n.4**


**6**



**BOCCOLA DI RITENZIONE** z1861  
PLASTIC BUSH  
DOUILLE PLASTIQUE  
FLASTIK BÜCHSE  
CASQUILLO

**Q.TY n.4**


**7**



**GOMMINO**  
z1857  
FAIRLEADER  
CHAUMARD  
GUMMI  
GOMA

**Q.TY n.-**


**8**



**GOMMINO**  
z1858  
FAIRLEADER  
CHAUMARD  
GUMMI  
GOMA

**Q.TY n.4**


**9**



**GOMMINO**  
z1858  
FAIRLEADER  
CHAUMARD  
GUMMI  
GOMA

**Q.TY n.4**

**10**



**DADO A.B. M6**  
FLANGIATO  
BOIT M6  
ECROU M6  
MUTTER M6  
TUERCA M6

**Q.TY n.4**

