

ATTACCHI SPECIFICI PER - SPECIFIC FITTING KIT FOR  
 KIT DE MONTAGE SPECIFIQUE POUR - SPEZIFISCHER MONTAGEKIT FÜR  
 ANCLAJE ESPECÍFICO PARA

# KEEWAY OUTLOOK 2009

125 - 150cc

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

1

**NON IN LUSO**  
 NOT INCLUDED  
 PAS INCLUS  
 NICHT INKLUDIERT  
 NO ESTA INCLUIDO

**Q.TY n.-**

2

**SUPPORTO**  
 SUPPORT  
 SUPPORT  
 HALTERUNG  
 SOPORTE

**Q.TY n.2(Dx-Sx)**

3

**RONDELLA Ø8mm**  
 WASHER Ø8mm  
 RONDELLE Ø8mm  
 SCHEIBE Ø8mm  
 ARANDELA Ø8mm

**Q.TY n.2**

4

**VITE TBEI M6x30mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO

**Q.TY n.4**

5

**BOCCOLA DI RITENZIONE Z1861**  
 PLASTIC BUSH  
 DOUILLE PLASTIQUE  
 PLASTIK BUCHSE  
 CASQUILLO

**Q.TY n.4**

6

**GOMMINO Z1858**  
 FAIRLEADER  
 CHAUMARD  
 GUMMI  
 GOMA

**Q.TY n.4**

7

**GOMMINO Z1857**  
 FAIRLEADER  
 CHAUMARD  
 GUMMI  
 GOMA

**Q.TY n.4**

8

**DISTANZIALE Z1862**  
 SPACER  
 ENTRETOISE  
 DISTANZSTUECK  
 DISTANCIADOR

**Q.TY n.4**

9

**DADO A.B. M6 FLANGIATO Z1863**  
 BOLT M6  
 ECROU M6  
 MUTTER M6  
 TUERCA M6

**Q.TY n.4**

