

RIDE CONNECTED

Blast your favorite tunes, talk over the intercom with your buddies, hear directions from your GPS and more, all through your headset. With built-in Bluetooth® capabilities, Quad HD camera, HD speakers and a microphone using Advanced Noise Control™, technology has never felt so minimal or freeing.

- Bluetooth® Integrated
- 1.6 Km (1.0 Mile) Intercom
- Quad HD Camera Integrated
- Four-Way Intercom
- Unibody Design
- Smart Audio Mix™
- Advanced Noise Control™
- WiFi Enabled
- Audio Multitasking™
- Audio Source Priority

GETTING STARTED

- This product comes with a Quick Start Guide, which is a basic version of the User's Guide. **A FULL VERSION OF THE USER'S GUIDE CAN BE DOWNLOADED AT SENA.COM.**
- Update this product for free with the latest firmware to fully enjoy the new advanced features built into this product. Visit SENA.COM to see how to update your product.
- Users can follow Sena on Facebook, YouTube, Twitter and Instagram to receive the most up to date information on products, helpful tips and all other announcements regarding Sena products.

SENA Sena Technologies, Inc.
SENA.COM
 Customer Support: support.sena.com

10C PRO

GETTING STARTED


GETTING STARTED

How to Use This Guide

The legend and callouts are here to help you read the illustrations. New technology can be confusing, but we've created a simple way to perform actions using illustrations.



Buttons



GETTING STARTED

Icon Legend

TAP 1x Tap button/Jog Dial the specified number of times

HOLD 10s Press and Hold button/Jog Dial for the specified amount of time



ROTATE L **ROTATE R** **ROTATE** Rotate Jog Dial clockwise (right) or counterclockwise (left).

ROTATE L **ROTATE R** **ROTATE** Rotate while Pressing Jog Dial clockwise (right) or counterclockwise (left).

"Hello" Audible prompt

QUICK START GUIDE

Product Details




10C PRO

QUICK START GUIDE

QUICK START GUIDE

Installation



Basic Operations


Powering On



Volume Up



Powering Off




Volume Down




QUICK START GUIDE

Checking the Battery Level

Visual Method




Audible Method



Bluetooth Pairing (Phone, MP3, GPS)

Mobile Phone Pairing



"Phone pairing"

Steps continued...


LED STATUS = Alternating blue and red flashing lights indicate **device is now discoverable.**

PIN NUMBER = 0000


QUICK START GUIDE

Mobile Phone

Answer a Call



End a Call



Music Controls

Play/Pause



Track forward



Track backward



QUICK START GUIDE

Camera Controls

Camera On



Camera Off



Taking Photos



"[Shutter sound]"

Intercom

Up to three other people can be paired with the headset for Bluetooth intercom conversations.

Pairing Headset A with Headset B



Start/End Intercom with Headset B



"Intercom pairing"

YOU = Flashing blue LED confirms intercoms are paired.

or = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.

10C PRO

QUICK START GUIDE

QUICK START GUIDE

Intercom

Up to three other people can be paired with the headset for Bluetooth intercom conversations.

Pairing Headset A with Headset B



Start/End Intercom with Headset B



"Intercom pairing"

YOU = Flashing blue LED confirms intercoms are paired.

or = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.

LED STATUS = Flashing blue LED confirms intercoms are paired.


10C PRO

QUICK START GUIDE


QUICK START GUIDE

Group Intercom


Start Group Intercom




START GROUP INTERCOM



END GROUP INTERCOM



"Group intercom terminated"



LED STATUS



FM Radio On



FM Radio Off



SEEK FORWARD



SEEK BACKWARD

QUICK START GUIDE

Headset Configuration Menu

Accessing the Headset Configuration Menu



CONFIG. MENU



"Configuration menu"



EXECUTE



"[Menu prompt]"




"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"

QUICK START GUIDE

Camera Configuration Menu

Accessing the Camera Configuration Menu




CAMERA CONFIG. MENU



"Camera Setup"



ENABLE/DISABLE



"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"


QUICK START GUIDE

Sena Device Manager

The Sena Device Manager allows you to upgrade the firmware and configure its settings directly from your PC or Apple computer. Download the Sena Device Manager, please visit sena.com.

Sena Smartphone App

The Sena Smartphone App allows you to configure the headset settings. Download the Sena Smartphone App for Android and Apple operating systems from sena.com.



QUICK START GUIDE

Sena Camera App

The Sena Camera App allows you to see a live preview from the camera, manage recorded videos as well as configure the video settings using the built-in WiFi feature on camera system. When the camera and the Sena Camera App are connected, the camera is synchronized with the smartphone's date and time. Download the Sena Camera App for Android and Apple operating systems from sena.com.

Sena Smartphone App

The Sena Smartphone App allows you to configure the headset settings. Download the Sena Smartphone App for Android and Apple operating systems from sena.com.




QUICK START GUIDE

Troubleshooting

Factory Reset



"Factory reset"



Fault Reset



"Note: Fault Reset will not restore the headset to factory default settings."



LED STATUS



EXECUTE



"[Menu prompt]"



"[Menu prompt]"



"[Menu prompt]"

QUICK REFERENCE

Basic Operations


Power on / Power off



Volume up / Volume down



Answer phone call



End phone call



Reject phone call



Call transfer while on the phone



Voice dial



Speed dial



QUICK REFERENCE

Music

Play/Pause music



Track forward



Track backward



Camera On



Camera Off



Start/Stop recording



Taking Photos



FM radio on/off



Seek forward



Seek backward



QUICK REFERENCE

Intercom

Intercom pairing



Start/End intercom




End all intercoms



Start Group Intercom



End Group Intercom



10C PRO

MOTORCYCLE BLUETOOTH® CAMERA AND COMMUNICATION SYSTEM