



SHIDO[®]

CONNECT

Quick Start Guide



IMPORTANT

Your SHIDO Connect can always supply power like any other battery. This power will never be shut down. Only the Bluetooth function has a sleep mode in order not to drain your battery when not using the motorcycle. Your new battery arrives with the Bluetooth function in sleep mode.

WARNING

When your motorcycle is equipped with a parasite power consumer like an alarm system, make sure to connect your battery with a maintenance charger when not using your motorcycle for more than one week. We recommend using a SHIDO DC3 Lithium charger.

1



Install the 'SHIDO Connect' app on your smartphone



Activate Bluetooth in the settings of your phone



Open the app

2




Activate Bluetooth on your battery:




Press and hold the ON/OFF button for 3 seconds



You will see 3 green lights flashing when Bluetooth is turned on



3



There are 2 ways to connect your phone with your battery:




Battery search

Get a list of all active Bluetooth devices nearby

You can recognize your battery by its unique number

MAC: 58:7A:62:27:5E:DB



Scan QR code

Scan the QR code on your battery and your unique number will appear



You can use the flashlight of your smartphone when you're in a dark environment



Connect your phone with a battery by checking the box for that battery



Ready to use

You can now install the battery into your motorcycle and put it into service



One smartphone can be connected to up to **7** batteries, **but** one battery can be connected to only one phone. Only when you disconnect your phone from a battery, a different smartphone can be connected to that battery.

4



When you select a connected battery, the state of charge (SOC) appears (%)



Total voltage (4 cells in series)



Temperature inside the battery



Voltage (V) of each individual lithium cell

■ > 3,31V


■ 3,29V - 3,31V

■ 3,26V - 3,29V

■ < 3,26V




Swipe to the right to see the technical specifications and basic info of your battery





Swipe to the left to get an overview of your alarm records



5



To activate the Bluetooth sleep mode **manually**:



Press and hold the ON/OFF button of your battery for 3 seconds. You will see 1 red light flashing. ●



OR go to the basic information screen and press *Bluetooth sleep*

When the Bluetooth connection is not used for > 15 days, sleep mode will be activated **automatically**

6



To switch off the Bluetooth sleep mode **manually**:



Press and hold the ON/OFF button of your battery for 3 seconds **OR** charge the battery by using an external charger



You will see 3 green lights flashing when Bluetooth is turned on

Charging the battery by starting the engine will reactivate the Bluetooth function **automatically**