10U for Shoei GT-Air
Quick Start Guide





15.Jun.

Installation



Charging



Button Operation

Tap — Tapping

Tap Tap — Double Tapping

1" — Press for 1 sec

5" 12" — Press and Hold

Move — Move Joystick

1" — Move and Hold for 1 sec

Power On/Off

\+ / – — 1" Press

Volume Adjustment

Joystick — Move

Phone, Music Pairing

Joystick — 5" Press

Select **Sena 10U**

Enter 0 0 0 0 PIN

Music Operation

▶ / ❚❚ — Joystick — 1" Press

◀◀ / ▶▶ — Joystick — 1" Move

Mobile Phone Call Making and Answering

Answer	Rear Button	Tap
End	Rear Button	Tap
Voice Dial	Rear Button	Tap
Speed Dial	Rear Button	Tap Tap (Double Tap)
Reject	Front Button	2" Press

Intercom Pairing



Intercom Start/End



Radio On/Off

Radio Seek Stations



Radio Scan Up FM Band

Save to preset while scanning

Radio Move to Preset Station

Radio Save or Delete Preset



Setting

Configuration Menu

Using the Sena Device Manager

Connect the headset to your computer via a USB cable. Launch the Sena Device Manager and click **DEVICE SETTING** to configure the headset settings.

For details about downloading the Sena Device Manager, please refer to the leaflet included in the package.

Using the Sena Smartphone App

1. On your smartphone, download the Sena Smartphone App for Android or iPhone from Google Play or App Store. Please refer to www.sena.com/app for more details.
2. Pair your smartphone with the headset.
3. Run the Sena Smartphone App. Swipe the screen to the right and tap Setting to configure the headset settings.

Troubleshooting

Handlebar Remote Disconnection

If the Handlebar Remote becomes disconnected with your headset, recharge the Handlebar Remote or go through the pairing process again. Meanwhile, you can use the headset control buttons to operate the headset. Please refer to the User’s Guide at www.sena.com for details on headset control button operations.

Factory Reset

If you want to restore the 10U to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

Fault Reset

If the 10U is not working properly for any reason, reset by gently pushing the pin-hole reset button located on the left speaker.

A full version of the manual is downloadable at www.sena.com.

Sena Technologies, Inc.
www.sena.com
Customer Support: support.sena.com
E-mail: support@sena.com